Smart Electric Tail Gate Lift INSTALLATION MANUAL

2019 Geely Binyue

NOTE

1. TO ensure safety & normal usage of our 6. REMOVE automotive components and Joints must be well insulated to prevent short circuits.

8. CONNECT each harness according to

Rear button wire 9. DO not change the wires or accessorie A. Connect to rear button C. Control box port -8



Wire Definition

A.Connect with power supply device -A

Power wire

B.Control box port -2

C.Control box port -1

D.Select the front button


OBD adapter A. OBD in B. OBD out C. Connect to bus box wire -C




01-02

Bus box wire A. Front button terminal B. Connect to bus box C. Connect to communication -C D. Connect to power wire -D

original car




Power supply unit A. Control box port -9 B. Handle unlocking wire of the C. Tailgate lock wire




A.Control box port -3 B.Connect to lock -A



A. Connect to rear button wire-B A. Connect it with the electric lock control wire -A B. Emergency rope



A. Connect to power wire -A B. Connect to fuse slot of the original car



A. Connect to Control box port -4 B. Connect to Control box port -5-6

Installation Steps





2. Remove the car body ball stud of the original car.

3. Install the electric tailgate car

body support of our company.

4. Remove the of the original car tailgate ball stud.

1. 2019 Geely Binyue.

03-04



original car.

5. Replace it with the electric tailgate car body ball stud of

our company.



5652323010000.v1

Remote control operation: long-press the trunk button.

All above is subject to change without prior notice. After installation, close the tail gate manually, so that the system can initialize.



8. Position of drilling a hole to



9. Remove the small trim board in the middle of tailgate.



10. Remove the screws

(one in the left and right sides



respectively).



11. Remove the small trim board on both sides of the tailgate, remove the screw (one in the left and right sides respectively).

right sides respectively).



13. Remove the screw from the handle of the tailgate, take out the tailgate handle.



14. Remove the tailgate trim



15. Remove the tailgate lock of the original car.

Installation Steps





driving wire.






20. Position of supply power for fuse, connect it with the power wire, lay the power wire to the tailgate.



21. Connect the lock control wire and the tailgate lock driving wire of the original car.



22. Connect to the handle switch wire of the original car (the wire color of the original car is blue-black).



23. Position of installing the grounding wire.



24. Position of installing the control box (paste it on the tailgate with adhesive tape).



25. Position of installing the front button.



26. Position of installing the rear button (install it on the small trim board of the emergency switch on the big trim board of the tailgate).




6. Remove the air spring of the



7. Install the electric stay bar.



Installation Steps



12. Remove the triangle trim board on both sides of big trim board of the tailgate, remove the screw (one in the left and



17. Install the lock trim board.

16. Install the electric lock.

07-08



18. Connect the electric lock



19. Position of connecting OBD.

